

#### 1.0 SCOPE

This document describes the correct procedure for the assembly of the ML-XT connector system, including contact insertion, wedgelock insertion/withdrawal, contact removal and connector mating/unmating.

#### 2.0 PRODUCT INFORMATION

	DESIGN CHARACT	ERIST	ICS		PERFC	RMANCE CHARA	CTERISTICS		
de: sho	e-piece plug housing sign, permanently bor ot LSR (liquid silicone olding technology	nded by	v two-	Prevents fluid ingress; system is IP68-rated and J2030 power-wash test capable Prevents loss/ misalignment of seal; ensures repeatable retention during unmating and mating of plug and receptacle					
ind	op in replacement for lustry standard conne	ctors			Achieves superior reliability without the need for costly re-design				
	ar seals made from H nsistency rubber)	ICR (ni	gn		material; p	preater tear-resistan prevents damage to sertion/ extraction			
Lat	tched rear covers			Locks in rear HCR seals Allows for flexible cable exits and cable movement whilst maintaining optimum seal position to prevent leak paths					
sup HC	ig and receptacle hou oplied pre-assembled R rear seals locked-i vers	with in	ternal	Reduces inventory, assembly time and costs for harness manufacturers and prevents loss of rear seals for a cost-competitive mated system					
	lises Molex proven XI h current ratings up to			S	Supports tooling widely used at harness makers				
Hig 11 suf	gh terminal retention f 1N (Subject to use of ficient tensile strength 1N load)	orce; e: cable v	xceeds vith		Withstands high axial pull-out forces per J2030 specification				
	edgelock / TPA (Term surance) loaded after				Locks term electrical c	ninals in position for contact	secure		
	ig housing features in				Ensures secure mating of plug and receptacle				
9 c	olour-coded housings	s availa	ble		Enables easy visual mating of harnesses to prevent mis-mating				
	ying options available Iltiple circuit sizes	across	6			nis-mating of differe	nt circuits		
Un	mating features prese ention fingers	ent on t	ermina	PR	Enables ea	asy extraction of ter	minals		
				/ F	Enablester				
HIS DOCUMENT (	CONTAINS INFORMATION THAT IS P	ROPRIETAR	RY TO MOLE	EX ELECTRONIC TE	CHNOLOGIES, LLC	AND SHOULD NOT BE USED WIT	HOUT WRITTEN PERMISSION		
<u>REVISION:</u>	<u>EC INFORMATION:</u> EC No: <b>622866</b>	<u>TITLE:</u>		ML-XT A	SSEMB	LY GUIDE	SHEET No		
<b>A5</b>	DATE:						<b>2</b> of <b>17</b>		
DOCUMEN	T NUMBER:	DOC TYPE:	DOC PART:	CREATED / F	REVISED BY:	CHECKED BY:	APPROVED BY:		
93	34430010	PS	<b>A</b>	JFLET	CHER				

TEMPLATE FILENAME: APPLICATION\_SPEC[SIZE\_A4] (V.4).DOCX

#### 3.0 REFERENCE DOCUMENTS

This instructions manual contains supplemental information pertaining to the Molex ML-XT sealed connector system. Additional information such as keying, colours etc... can be found on the Sales & Assembly drawings:


93443\*\*\*\* PSD (multiple documents) 84525\*\*\*\* PSD (multiple documents) Drawings 84524\*\*\*\* PSD (multiple documents) 936400020 PSD 936410010 PSD ATS-63824-5300 934941000 PSD 845241000 PSA


#### 4.0 PRODUCT SUMMARY




Plug & Receptacle Sales Drawings Socket Contact, (Stamped & Formed), Sales

Pin Contact, (Stamped & Formed), Sales Drawings Socket Contact, (Solid), Sales Drawings Pin Contact, (Solid), Sales Drawings ML-XT Removal Tool Specification ML-XT Blind Cavity Plug XRC Terminal Application Specification







	<u>EC No:</u> 622866			ML-XT ASSEMB	LY GUIDE		
A5	DATE:						5 of 17
DOCUMEN	T NUMBER:	DOC TYPE:	DOC PART:	CREATED / REVISED BY:	CHECKED BY:	APPRO	OVED BY:
93	34430010	PS	Α	JFLETCHER			
				TE	MPLATE FILENAME: APPLICATIO	N SPECISIZE	A41 (V.4).DOCX

# **MOIOX** APPLICATION SPECIFICATION **4.3 PRODUCT IDENTIFICATION** All parts are laser etched with: Date Code (D WW YY) • $\circ$ D = DAY of the week (1 To 7) $\circ$ WW = Week of the year (01 to 52) • YY = Last two digits of the Year (01 - 99)Note – Location for Date Codes can be found on Customer Drawings **MOLEX DATE CODE** EASE

THIS DOCUMENT CONTAINS INFORMATION THAT IS PROPRIETARY TO MOLEX ELECTRONIC TECHNOLOGIES, LLC AND SHOULD NOT BE USED WITHOUT WRITTEN PERMISSION.									
REVISION:	EC INFORMATION:	TITLE:					SHEET No.		
	<u>EC No:</u> 622866			<b>ML-XT ASSEMB</b>	LY GUIDE				
A5	DATE:						6 of 17		
DOCUMEN	T NUMBER:	DOC TYPE:	DOC PART:	CREATED / REVISED BY:	CHECKED BY:	APPRO	OVED BY:		
93	34430010	PS	<b>A</b>	JFLETCHER					
				TE	MPLATE FILENAME: APPLICATIO	N_SPEC[SIZE	_A4] (V.4).DOCX		

#### 4.4 CONNECTOR ASSEMBLY


#### 4.4.1 TERMINAL CRIMPING

Crimping tools provide lower total installation and maintenance costs. However, controls are required to help ensure that the proper crimp tools designed for the type and size contact are used, the pin or socket is properly inserted into the tool, the wire insulation is stripped properly, and the wire fully inserts into the contact.


When a crimp is completed, the crimp can be visually inspected. The inspector should check for:

- The removed insulation should expose a conductor length that is specified in the application tooling specification.
- Wire strands intact.
- All wire strands are in the conductor crimp barrel.
- Wire is inserted to the correct depth in the terminal.
- The Insulation crimp heights and width should be equal to or less than that of the cable it is crimped to (Note: Poor Insulation crimps can lead to difficult terminal extraction)


#### ACCEPTABLE CRIMPS



Solid Contact (Cable Strip Length 6.35 to 7.92mm Reference)



Stamped & Formed Contact





#### UNACCEPTABLE CRIMPS

#### 4.4.2 TERMINAL INSTALLATION

Grip the wire no less than 10mm for smaller diameter cable (1.2mm to 2.4mm) & no less than 20mm for larger diameter cable (2.4mm to 3.6mm) from the terminal insulation crimp align terminal on centre with the appropriate opening in the back cover and insert through the circuit opening in the back seal. For insertion of flexible cables see section 4.4.3.

If resistance is encountered, retract the terminal and adjust the angle of insertion. Continue inserting the terminal until it stops and locks up on the lock finger with an audible click. Once the connector is fully populated insert the wedgelock/TPA. The wedgelock should 'click' into position. Plug Connector/Socket Terminal shown - use same method for Receptacle/Pin.







SHEET No.

8 of 17

**!!!!!!DO NOT INSTALL THE TERMINATED CABLES AT AN ANGLE!!!!!!** 





<u>DATE:</u>					
DOCUMENT NUMBER:	DOC TYPE:	<u>DOC</u> PART:	CREATED / REVISED BY:	CHECKED BY:	APPROVED BY:
934430010	PS	Α	JFLETCHER		
			TE	MPLATE FILENAME: APPLICATIO	N_SPEC[SIZE_A4] (V.4).DOCX



To ensure secure terminal insertion: Follow the Push, Click, Pull Method of terminal insertion

Never try insert the terminal when wedgelock (TPA) is already in position.






THIS DOCUMENT CONTAINS INFORMATION THAT IS PROPRIETARY TO MOLEX ELECTRONIC TECHNOLOGIES, LLC AND SHOULD NOT BE USED WITHOUT WRITTEN PERMISSION.										
C INFORMATION:	TITLE:					SHEET No.				
<u>No:</u> 622866			<b>ML-XT ASSEMB</b>	LY GUIDE						
<u>TE:</u>						9 of 17				
JMBER:	DOC TYPE	DOC PART	CREATED / REVISED BY:	CHECKED BY:	APPRO	OVED BY:				
30010	PS	Α	JFLETCHER							
			ТЕ	MPLATE FILENAME: APPLICATIO	N_SPEC[SIZE_	A4] (V.4).DOCX				
( ]	C INFORMATION: No: <b>622866</b> TE: IMBER:	C INFORMATION:   TITLE:     No:   622866     TE:	C INFORMATION:   TITLE:     No:   622866     TE:   DOC     IMBER:   DOC     TYPE:   PART:	C INFORMATION:   TITLE:     No:   622866   ML-XT ASSEMB     IE:   IMBER:   DOC TYPE:   DOC PART:   CREATED / REVISED BY:     30010   PS   A   JFLETCHER	C INFORMATION:   TITLE:     No: 622866   ML-XT ASSEMBLY GUIDE     IE:   IMBER:     JMBER:   DOC TYPE:     A   CREATED / REVISED BY:     GOOTO   PS	C INFORMATION:   TITLE:     No: 622866   ML-XT ASSEMBLY GUIDE     TE:   DOC   DOC   PART:   CREATED / REVISED BY:   CHECKED BY:   APPRO				



### **APPLICATION SPECIFICATION**

#### 4.4.3 TERMINAL INSERTION WITH FLEXIBLE CABLE



#### Figure 5: M81969/14-03 Insertion/Extraction Tool for size 16 contacts

Some cables can be difficult to insert into the connector cavities as they tend to bend, to avoid seal damage it is recommended that, on flexible cables, the M81969/14-03 Insertion/Extraction Tool is used to aid the installation of the contact.

To avoid any damage and ensure correct installation follow the below steps:


1. Place the wire over the slot in the tool tip. Apply light pressure on the wire until the tip spreads and allows the wire to enter the tip.



2. Slide the contact wire barrel into the insertion (blue) end of the tool tip until the tip butts against the shoulder of the contact.




3. Align the contact and tool tip with the desired connector contact cavity.



THIS DOCUMENT O	THIS DOCUMENT CONTAINS INFORMATION THAT IS PROPRIETARY TO MOLEX ELECTRONIC TECHNOLOGIES, LLC AND SHOULD NOT BE USED WITHOUT WRITTEN PERMISSION.									
<b>REVISION:</b>	EC INFORMATION:	TITLE:					SHEET No.			
	EC No: 622866			ML-XT ASSEMB	LY GUIDE					
A5	DATE:						10 of 17			
DOCUMEN	T NUMBER:	DOC TYPE:	DOC PART:	CREATED / REVISED BY:	CHECKED BY:	APPRO	OVED BY:			
93	34430010	PS	Α	JFLETCHER						
				TE	MPLATE FILENAME: APPLICATIO	N_SPEC[SIZE_	_A4] (V.4).DOCX			



4. Hold the wire against the serrations in the tool handle and push the tool straight into the contact cavity until the contact bottoms.



5. Remove the tool from the contact. Pull back lightly on the wire to ensure that the contact is secure in the cavity.




PRE-REI	EASE
PRE-REI REFEF	ONLY

REVISION:   EC INFORMATION:   TITLE:   SHEET NO     EC No:   622866   ML-XT ASSEMBLY GUIDE   SHEET NO											
A5 <u>EC No:</u> 622866 ML-XT ASSEMBLY GUIDE 11 of 17	THIS DOCUMENT (	THIS DOCUMENT CONTAINS INFORMATION THAT IS PROPRIETARY TO MOLEX ELECTRONIC TECHNOLOGIES, LLC AND SHOULD NOT BE USED WITHOUT WRITTEN PERMISSION.									
A5 11 of 17	<b>REVISION:</b>	EC INFORMATION:	TITLE:					SHEET No.			
A5 DATE: 11 of 17		<u>EC No:</u> 622866			<b>ML-XT ASSEMB</b>	LY GUIDE					
	A5	DATE:						11 of 17			
DOCUMENT NUMBER:     DOC TYPE:     DOC PART:     CREATED / REVISED BY:     CHECKED BY:     APPROVED BY:	DOCUMEN	T NUMBER:			CREATED / REVISED BY:	CHECKED BY:	APPRO	OVED BY:			
934430010 PS A JFLETCHER	93	34430010			JFLETCHER						
TEMPLATE FILENAME: APPLICATION_SPEC[SIZE_A4] (V.4).DOCX					TE	MPLATE FILENAME: APPLICATIO	N_SPEC[SIZE_	_A4] (V.4).DOCX			


#### 4.4.4 TERMINAL EXTRACTION

- 1. Lever the Wedgelock from the housing using the flathead screwdriver end of the removal tool (63824-5300) Take care not to damage the 2-shot seal (For Receptacle wedgelock use hooked end of tool).
- To remove the contacts, gently pull the cable backwards while at the same time releasing the locking finger by moving it away from the terminal/contact with the flathead screwdriver end of the removal tool. (For 3cct Receptacle wedgelock removal use needle nose pliers)
  Simply pull out the terminated cable slowly and on centre.
- DO NOT PULL OUT CABLES AT AN ANGLE ONLY EXTRACT ONE CABLE AT A TIME!





#### 4.4.5 TERMINAL EXTRACTION – 18cct CONNECTOR




STEP 1: With rear of connector pointed towards you, snap the removal tool (p/n: 63813-1900\*) over the cable of the contact to be removed



#### <u>STEP 2:</u>

Slide tool along the wire and carefully insert the tool into the cavity until it engages contact and resistance is felt.

NOTE: DO NOT TWIST OR INSERT TOOL AT AN ANGLE



<u>STEP 3:</u> Keeping the cable pressed against the removal tool gently pull out the cable.



<u>STEP 4:</u>


Pull contact wire assembly out of connector, taking care not to pull too quickly.

\* M81969/14-03 Insertion/Extraction Tool may also be used

HIS DOCUMENT CONTAINS INFORMATION THAT IS PROPRIETARY TO MOLEX ELECTRONIC TECHNOLOGIES, LLC AND SHOULD NOT BE USED WITHOUT WRITTEN PERMISSION.										
REVISION:	EC INFORMATION:	TITLE:					SHEET No.			
	<u>EC No:</u> 622866			<b>ML-XT ASSEMB</b>	LY GUIDE					
A5	DATE:						13 of 17			
DOCUMEN	T NUMBER:	DOC TVDE		CREATED / REVISED BY:	CHECKED BY:	APPRC	OVED BY:			
934430010		PS	<b>A</b>	JFLETCHER						
				ТЕ	MPLATE FILENAME: APPLICATIO	N_SPEC[SIZE_	A4] (V.4).DOCX			
		TYPE:	PART:	JFLETCHER						

#### 4.5 CONNECTOR MATING


Note and align both plug and receptacle connectors and keying features (if present). Begin mating procedure by sliding the two connectors together, press firmly until you hear an audible click from the primary latch.




THIS DOCUMENT CONTAINS INFORMATION THAT IS PROPRIETARY TO MOLEX ELECTRONIC TECHNOLOGIES, LLC AND SHOULD NOT BE USED WITHOUT WRITTEN PERMISSION.										
REVISION:	EC INFORMATION:	TITLE:					SHEET No.			
	<u>EC No:</u> 622866			<b>ML-XT ASSEMB</b>	LY GUIDE					
A5	DATE:						14 of 17			
DOCUMEN	T NUMBER:	DOC TYPE:	DOC PART:	CREATED / REVISED BY:	CHECKED BY:	APPRO	OVED BY:			
93	34430010	PS	<b>A</b>	JFLETCHER						
				TE	MPLATE FILENAME: APPLICATIO	N_SPEC[SIZE_	A4] (V.4).DOCX			

#### 4.6 CONNECTOR UNMATING


Depress the primary latch on the plug connector to fully disengage locking mechanism and then pull the plug connector out from the receptacle connector while keeping the primary latch depressed.





#### 4.7 HARNESS ROUTING


The cable shall exit 1.0mm beyond the connector housing, co-axial with the grommet sealing lips. Bending of the cable shall be performed beyond this point to the recommended cable manufacturer's bend radius.




#### 4.8 SEALING PLUG INSTALLATION AND REMOVAL

#### Step 1:


Holding the sealing plug with large diameter end away from the connector, gently apply downward pressure to force the sealing plug into the cavity.



Step 2: With perpendicular motion, apply downward pressure to the large diameter end of the sealing plug.



Step 3: Apply pressure until sealing plug is forced to stop by contact with the back cover. Visually inspect the sealing plug large diameter end to confirm it is flush with cavity opening. If multiple sealing plugs are used close together, the large ends may not sit flush due to tight spacing. Maximum allowable distance from top of sealing plug to grommet surface is 5.00mm.



#### 4.9 HEATSHRINK TUBING APPLICATION

1. When using the heatshrink adaptor option of the ML-XT connector, heatshrink tubing may be used to add extra strain relief to the system. Firstly, ensure all crimped cables are latched in place as outlined in section 4.4.2.



2. Slide the heatshrink tubing over the heatshrink housing adaptor as shown below.



3. Apply heat and allow the heatshrink tubing to shrink around the housing and cables.

